

- Press the **▲▼◀▶** buttons on your remote to move the highlight.
- Press the **OK/SEL** to make your selection.
- Press the **EXIT** button on your remote to return to watching TV.

Remote Control Features



ComSouth

www.comsouth.net

Note: Remote pictured may not reflect your actual remote. Basic functions should be the same.
* Amount of programming data varies by system.

Basic Remote Control Functions

Turning Power On and Off

Press **SYSTEM ON/OFF** to power both the TV and cable box on/off simultaneously.

Changing Channels

You can change channels one of three ways:

Press **CHANNEL ▲** or **▼** on the front panel of the receiver or the remote control to step through the channel selection.

Enter the number of the channel you wish to view using the number keys on the remote control.

Select the channel in the Interactive Program Guide.

Adjusting the Volume

Press **VOLUME ▲** or **▼** on the remote control to adjust the volume.

When you adjust the volume, the volume scale is displayed on the screen. Press **MUTE** on the remote control to toggle the sound on and off.

Handy Keys

Press **MENU** for quick access to settings and other useful features. If you are looking for something, you will probably find it in the menu.

Last

Press **LAST** to return to the previous screen or channel.

What's on tonight?

Press **GUIDE** to display the helpful on-screen programming guide.

As you navigate throughout the Guide, your current selection is highlighted in yellow, and a program or feature description appears on the screen. Please see sample at right.



Helpful Tip

NOTE: YOUR TV SHOULD BE ON CHANNEL 3 AT ALL TIMES!

Neighbors
servicing Neighbors



ComSouth
www.comsouth.net